

OVERHEAD  
CROSS  
ROAD

FROM  
SHOULDER  
ROAD

OVER  
HEAD  
UTILITY

Directional bore installing (2) 1 1/4" conduits

Installing (2) 1 1/4" conduits/fiber

Handhole placed over existing conduit



UTILITY  
WORK  
AHEAD

SHOULDER  
WORK

ROAD  
WORK  
AHEAD

**Date:** 5/11/2016 **Author:** CentraCom **Project:** Mosaic Network  
**Comments:**  
 Installing handhole on 200 W 13490 S. Directional drill road bore on 200 W 13490 S. Installing (2) 1 1/4" conduits/fiber

Taper, Buffer Zone & Sign Spacing				
Posted speed	Mini Taper Length	Length of Buffer	Min Sign Spacing	Devices Spacing
30	180'	200'	100'	15'
35	245'	250'	350'	20'
40	320'	305'	350'	27'
45	540'	380'	500'	45'
50	600'	425'	500'	50'
55	660'	485'	500'	55'
60	720'	570'	500'	60'
65	780'	645'	500'	65'