



Accessing existing handhole

Installing handhole

Installing (2) 1 1/4" conduits/fiber



**Date:** 6/8/2017 **Author:** CentraCom **Project:** Asphalt Zipper 700 S Pleasant Grove

**Comments:**

Installing (2) 1 1/4" conduits/fiber on south side of 700 S. Installing handholes. No asphalt cuts, directional drill.

Posted speed	Taper, Buffer Zone & Sign Spacing			
	Mini Taper Length	Length of Buffer	Min Sign Spacing	Devices Spacing
30	180'	200'	100'	15'
35	245'	250'	350'	20'
40	320'	305'	350'	27'
45	540'	380'	500'	45'
50	600'	425'	500'	50'
55	660'	495'	500'	55'
60	720'	570'	500'	60'
65	780'	645'	500'	65'