

Date: 6/8/2017 **Author:** CentraCom **Project:** Asphalt Zipper 700 S Pleasant Grove

Comments:

Installing (2) 1 1/4" conduits/fiber on south side of 700 S. Installing handholes. No asphalt cuts, directional drill.

Taper, Buffer Zone & Sign Spacing				
Posted speed	Mini Taper Length	Length of Buffer	Min Sign Spacing	Devices Spacing
30	180'	200'	100'	15'
35	245'	250'	350'	20'
40	320'	305'	350'	27'
45	540'	380'	500'	45'
50	600'	425'	500'	50'
55	660'	495'	500'	55'
60	720'	570'	500'	60'
65	780'	645'	500'	65'

Installing handhole

Road bore directional drill 40'

Installing (2) 1 1/4" conduits/fiber

Installing handhole

