

Date: 6/8/2017 Author: CentraCom Project: Asphalt Zipper 700 S Pleasant Grove

Comments:

Installing (2) 1 1/4" conduits/fiber on south side of 700 S. Installing handholes. No asphalt cuts, directional drill.

Taper, Buffer Zone & Sign Spacing				
Posted speed	Mini Taper Length	Length of Buffer	Min Sign Spacing	Devices Spacing
30	180'	200'	100'	15'
35	245'	250'	350'	20'
40	320'	305'	350'	27'
45	540'	380'	500'	45'
50	600'	425'	500'	50'
55	660'	495'	500'	55'
60	720'	570'	500'	60'
65	780'	645'	500'	65'



Installing (2) 1 1/4" conduit/fiber

Road bore directional drill

Installing handhole

ROAD WORK AHEAD

SHOULDER WORK AHEAD

ROAD WORK AHEAD

ROAD WORK AHEAD

ROAD WORK AHEAD

ROAD WORK AHEAD

SHOULDER WORK AHEAD

ROAD WORK AHEAD

ROAD WORK AHEAD