

Date: 7/19/2017 Author: CentraCom Project: UMPA Arrowhead Trail Salem

Comments:

Installing handholes. Installing 1 1/4" conduit/fiber.  
Road bore directional drill Arrowhead Trail/1200 W

Posted speed	Taper, Buffer Zone & Sign Spacing			
	Mini Taper Length	Length of Buffer	Min Sign Spacing	Devices Spacing
30	180'	200'	100'	15'
35	245'	250'	350'	20'
40	320'	305'	350'	27'
45	540'	380'	500'	45'
50	600'	425'	500'	50'
55	660'	495'	500'	55'
60	720'	570'	500'	60'
65	780'	645'	500'	65'



Road bore directional drill

Installing handhole

Installing 1 1/4" conduit/fiber

Installing handhole