www.invarion.com

Devices Spacing

Installing handhole 10' back of of sidewalk.

Directional drill oac-bore 70'

Installing 341' 11/4" conduit/fiber

Installing handhole 10' back of sidewalk.

> Directional drill road bore 42'

 Date:
 10/12/2017 Author:
 CentraCom Project:
 Coabalt Village Heritage Crest Way Bluffdale

 Comments:
 Installing 114/4 conduit/ber on east side of
 Tapt Buff Zorel Sigs Spring

 Noeil Neison Dr.:
 Directional dirl coad bore 42
 Patt Spet Suff Zorel Sigs Spring

 Noeil Neison Dr.:
 Tapt Buff Zorel Sigs Spring
 Patt spet Length of Buff Win Sigs Spat

 Orossing Noeil Neison Dr.:
 Tapt Spring Tom Sign Spat
 20
 Wing Spat

1000

180 200' 100' 245' 320' 540' 600' 250 305 350 27' 380 500 45' 425' 500 50' 660' 720' 780 501